



T006 Long Slug Bracket

Installation instructions

Package contents: T006 Long Slug Bracket, metal slug, 2 non-magnetic M4 bolts

NB – If bracket is to be removed it is advisable to apply silicon grease to slug and screws prior to fitting.

- Drop the slug into the mast slot through the gate using a tool to catch the slug at the desired height.
- Fix the slug in place with a single bolt.
- Offer up the bracket, attaching loosely to the slug with the second bolt.
- Now remove and refit the first bolt.
- Tighten both bolts.
- Attach the cradle to the bracket using the stainless bolts provided with the Compass.

Now simply clip in your product into its cradle each time you sail.

WARNING

- Compass is accurate only when mounted within 20° of the vertical.
- Do not lean compass to port or starboard.
- Do not mount within 2' or 0.6 m of magnetic objects.
- Note that a conventional compass is a magnetic object.

For further details contact your dealer or www.raymarine.com

UU022-Rev4